


## Phone's Status Icons

The Status Bar appears at the top of every screen. It displays icons indicating that you've received notifications (on the left) and icons indicating the phone's status (on the right), along with the current time.



If you have more notifications than can fit in the Status Bar, a plus icon  prompts you to open the Notifications panel to view them all. To open the Notifications panel, tap and drag the Status Bar down.

The following icons indicate the status of your phone.












### Call icons

	Muted microphone during a call		Missed call
	In call		In call using Bluetooth device
	Speaker on		Privacy call

### Calendar and Alarm icons

	Alarm set		Calendar event
---	-----------	---	----------------






















### Email and Messaging icons

	New email received		Failed to send email
	New message received		High priority message received
	Failed to send message		New voicemail received
	New visual voicemail received		New voicemail playing
	Google Talk message received		Gmail received
	Select input method		










### Sound icons

	Music playing		Silent mode
	Vibrate mode		Phone jack connected















## Network icons

	4G network connected		4G network in use
	Downloading data through 4G network		Uploading data through 4G network
	3G network connected		3G network in use
	Downloading data through 3G network		Uploading data through 3G network
	Downloading data		Uploading data
	Acquiring GPS data		GPS on
	No service		Weak network signal
	Strong network signal		Connected to network extender service
	Airplane mode		Roaming
	Location service on		Location service off
	Download complete		

## Connectivity icons

	Weak Wi-Fi signal		Strong Wi-Fi signal
	USB debugging connected		USB connected
	Bluetooth on		Bluetooth device connected
	USB tethering on		Mobile Hotspot on
	Wi-Fi Direct on		

## System icons

	SmartShare on		More notifications available
	System error		SD card inserted
	Preparing SD card		SD card error
	No SIM card		Unknown SIM card
	Sync in process		Sync error
	Battery empty		Battery full
	Battery charging		Battery status unknown