


Phone's Status Icons

The Status Bar appears at the top of every screen. It displays icons indicating that you've received notifications (on the left) and icons indicating the phone's status (on the right), along with the current time.



If you have more notifications than can fit in the Status Bar, a plus icon  prompts you to open the Notifications panel to view them all. To open the Notifications panel, tap and drag the Status Bar down.

The following icons indicate the status of your phone.












Call icons

	Muted microphone during a call		Missed call
	In call		In call using Bluetooth device
	Speaker on		Privacy call

Calendar and Alarm icons

	Alarm set		Calendar event
---	-----------	---	----------------






















Email and Messaging icons

	New email received		Failed to send email
	New message received		High priority message received
	Failed to send message		New voicemail received
	New visual voicemail received		New voicemail playing
	Google Talk message received		Gmail received
	Select input method		











Sound icons

	Music playing		Silent mode
	Vibrate mode		Phone jack connected















Network icons

	4G LTE network connected		4G LTE network in use
	Downloading data through 4G LTE network		Uploading data through 4G LTE network
	3G network connected		3G data network in use
	Downloading data through 3G network		Uploading data through 3G network
	Downloading data		Uploading data
	Acquiring GPS data		GPS on
	No service		Weak network signal
	Strong network signal		Connected to network extender service
	Airplane mode		Roaming
	Location service on		Location service off
	Download complete		

Connectivity icons

	Weak Wi-Fi signal		Strong Wi-Fi signal
	NFC on		USB debugging connected
	USB connected		Bluetooth on
	Bluetooth device connected		USB tethering on
	Mobile Hotspot on		Wi-Fi Direct on

System icons

	SmartShare on		More indicator
	System error		SD card inserted
	Preparing SD card		SD card error
	No SIM card		Unknown SIM card
	Sync in process		Sync error
	Battery empty		Battery full
	Battery charging		Battery status unknown